




1. Drill holes apply plastic anchors with screws
2. Use a screw driver to tight it up
3. Put it in place
4. Apply the side screws