


①

Indicator instructions:

1. The flashing green light indicates charging.
2. The steady green light indicates fully charged.

Note: Open the waterproof gasket before charge .
Don't forget to close it after full charge.





②

Touchdimmer:


Touch1=100% of light-4 hours runtime
Touch2=40% of light-10 hours runtime
Touch3=10% of light-50 hours runtime
Touch4=ON/OFF

Touch dimmer



Charging Cable

Plug adapter



Note:

Charge time: 3H(1A Charger adapter)

Charging Cable and Plug adapter included, Max Current 2A

