



1



Turn off the general switch

2




Item No.	A	B	C	D	E
9006010	800	800	46	431	431
9006011	1200	700	46	731	531

2 Select hanging direction


Select hanging direction

3




Drill holes and apply screws

4




Connect the wires

5




Put it in place

6



Plug It Into Socket



LED ON/OFF Demister ON/OFF