



1




Turn off the general switch

2




Select hanging direction

3




Drill holes and apply screws

4




Adjust

5




Turn on the general switch

6



Plug It In



LED ON/OFF Demister ON/OFF