



1



Turn off the general switch


2



Item No.	A	B	C	D
9006114	650	1350	210	305


Select hanging direction

3




Drill holes and apply screws

4




Connect the wires

5




Put it in place

6



Plug It Into Socket



Demister ON/OFF



LED ON/OFF