




1. Insert the bulb
2. Apply the cap by rotate
3. Plug it in power to turn it on/ off

