



1




Turn off the general switch

2




Untie screws & remove upper part

3




Fix the base on the ground
by applying anchors with screws
& connect wires

4



Apply side screws

5



Turn on the general switch

6

