

NOVA LUCE

9041106


1




Turn off the general switch



7



Turn on the general switch



This luminaire allows you to adjust the colour temperature across four preset levels (2200K/2700K/3200K/4000K) by sliding the colour temperature adjustment control inside the lamp housing.

1. Turn off general switch
2. Remove the side screws
3. Remove the element
4. Get the wire through
5. Apply the element
6. Apply side screws
7. Turn on the general switch