

NOVA LUCE

9041123


1




Turn off the general switch



9



Turn on the general switch



1.The colour temperature can be adjusted at 2200K/2700K/3200K/4000K by pressing the colour temperature adjustment button on the light side.

2.Press and hold for 4 seconds to lock or unlock the colour temperature, the light flashes once when locked and twice when unlocked.

1. Turn off general switch
2. Remove the side screws
3. Remove the element
4. Get the wire through
5. Apply screws
6. Connect the wires
7. Apply the element in to place
8. Apply side screws
9. Turn on the general switch

www.novaluce.com