
NOVA LUCE


9041130


1



Turn off the general switch

2






1.The colour temperature can be adjusted at 2200K/2700K/3200K/4000K by pressing the colour temperature adjustment button on the light side.

2.Press and hold for 4 seconds to lock or unlock the colour temperature, the light flashes once when locked and twice when unlocked.

7



Turn on the general switch

1. Turn off general switch
2. Dismantle the product
3. Get the wire through
4. Connect the wires
5. Apply screws
6. Apply the element in to place
7. Turn on the general switch

www.novaluce.com