

WARNING!









Please read the following instructions carefully

IMPORTANT:

Although LED runs on a very low voltage,

always cut off the power supply before installing the LED light or subjecting it to maintenance.

Unauthorized alterations or tampering of the product will invalidate all the conditions of guarantee.

①  Turn off the general switch	② <table border="1"> <tbody> <tr> <td>9050920</td> <td>5.8x5.8 cm</td> </tr> <tr> <td>9065023:</td> <td>10.8x5.7 cm</td> </tr> <tr> <td>9065121:</td> <td>15x5.7 cm</td> </tr> </tbody> </table>  Create a CutOut	9050920	5.8x5.8 cm	9065023:	10.8x5.7 cm	9065121:	15x5.7 cm	③  Expose & connect wires
9050920	5.8x5.8 cm							
9065023:	10.8x5.7 cm							
9065121:	15x5.7 cm							
④  Put it in place by pressing the brackets upwards	⑤  Turn on the general switch	⑥ 9050920  9065023  9065121 						



- A. The installation must be done by competent electricians.
- B. Product can not be modified
- C. Make sure the power has been switched off before installation
- D. The product is a Class III luminaire and shall not be connected with a constant 350mA driver.
- E. The connection of the luminaire should be standard with 0.5mm²-1.5mm² conductor.
- F. The specification for the driver means determines on the voltage and the maximum number of luminaires per loop
- G. Power should never be regulated on the secondary side
- H. See the installations on the image

