

# NOVA LUCE

## LED water proof light Installation and Operation Manual


Please read the following instructions carefully to ensure that mounting operation will be carried out in the right way .These instructions should be properly preserved for future reference.

### Specifications


| Item<br>Data          | LG08M-06           | LG08M-12 | LG08M-15 |
|-----------------------|--------------------|----------|----------|
| RATED WORKING VOLTAGE | 220-240Vac 50-60Hz |          |          |
| Wattage               | 18W                | 36W      | 50W      |
| protection class      | II                 |          |          |
| protection            | IP65               |          |          |

### Safety tips

1. Use H07RN-F, 2x1.0mm<sup>2</sup> rubber cable.
2. Luminaire should be installed by authorized electrician only acc. to national wiring rules. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or similar qualified person in order to avoid a hazard.
3. The power supply must be deactivated prior to assembly, maintenance, exchanging the bulb or cleaning processes. Remove the fuse or switch the fuse to OFF and secure from reactivation.
4. Use a screwdriver to open the box.
5. Connect brown wire(L) to terminal L, blue wire (N) to terminal N.
6. Terminal box installed back, the terminal box must be installed the correct position.




1




Turn off the general switch

2




Parts

3




Drill holes

4




Open the product

5




Connect the wires

6




Drill holes apply plastic anchors with screws

7



Click the product in to place

8



Turn on the general switch

