



1




Turn off the general switch

2




Unscrew the screws from the rosette and take out the bracket.

3




Apply plastic anchors & Apply the screws

4




Connect the 3 wires.
Place the brackets and apply the side screws.

5





Rotate to the angle you like.

6



Turn on the general switch



2 options

