



1




Turn off the general switch

2




Drill holes, Insert plastic anchors
& Apply screws

3




Connect the wires

4




Apply the side screws

5




Turn on the general switch



NOVA LUCE

Infrared ray Remote control instructions



1.  Switch on the light, keep the memory of last time.
2.  Switch off the light.
3.  Brightness +: when the lamp is on, press and hold this button down to increase the brightness.
4.  Brightness -: when the lamp is on, press and hold this button down to increase the brightness.
5.  Color temperature +: hold down this button, color from yellow to white.
6.  Color temperature - : hold down this button, color from white to yellow.
7.  Color temperature switch: Yellow-Warm white-White.
8.  Nightlight mode: 10% brightness of Yellow light.

Remark:

The light also can be switched by regular wall switch, the color temperature can be changed if on and off the light within 5 seconds, the sequence:
Yellow light → Warm white → White → Night light