



1




Turn off the general switch

2




Untight screws x5 times
To dismant the product

3




Apply plastic anchors with screws

4




Connect wires

5



Tight screws x5 times
To fix it in place

6



Turn on the general switch

